

admin 0191 418 1000 sales 0191 418 1122 fax 0191 418 1001

technical data

LS200 SERIES PAGING LOUDSPEAKER STATIONS

27-211 TECPRO LS211T Loudspeaker station, **27-221** TECPRO LS211F Loudspeaker station, **27-241** TECPRO LS211TW Loudspeaker station,

1 CONNECTING THE STATION TO THE SYSTEM

"Loop-Through" Wiring - Two parallel wired connectors are provided on all table top stations to allow wiring to be looped through and on to the next station if required. The female connector is used as the input and the male connector as the output by convention.

LS211/T - Use 2-core screened cable and connect as shown in Diagram 1 using XLR-3 type connectors.

LS211/F - For ease of installation, these are provided with a plug which connects to incoming wiring using screw terminals. Wire as shown on the PCB or adjacent sticker using 2-core screened cable - See Diagram 2.

2 BASIC OPERATION

Volume - The volume can be altered to the required level by turning the volume control knob.


3 OVERRIDE CONTROL FUNCTION

The LS200 series station are equipped with a receive circuit for an ultrasonic (25kHz) tone generated elsewhere in the system. The generator (OG904) is usually fitted in the main or master station so that when in "talk" mode it can remotely control these types of outstation.


The override forces the system to listen at a preset volume even if the local volume control is turned right down. The override level can be set to the required volume by adjusting the override preset.


technical data


admin 0191 418 1000 sales 0191 418 1122 fax 0191 418 1001



District 1 Chemic 1 Line 1 Lin







XIR 4-Pin Connector for Headsets of Impolance less than 1000 (Per Bar)







Diagram. 2
Circuit wiring LSR1/P showing commercing play viewed from gone terminal side.



Dispuis 4





XLR 4-Pin Connector for Hexisets of Impedence more than $100\,\Omega$ (Per Rev)

Danton 5