



Technical Data Sheet

EDAC CONTACT REMOVAL TOOL

47-005 EDAC contact removal tool

PLEASE READ BEFORE USING REMOVAL TOOL

When using this tool to remove contacts from the insulator body of EDAC multipin connectors, please exercise caution and observe the following procedure:

1. Locate the forks of the extraction tool across the blade of the contact on the mating side of the insulator.
2. Push the tool into the insulator body until the FIRST resistance is felt.
3. APPLY ADDITIONAL PRESSURE to push the forks past the first resistance until the fork blades are FULLY INSERTED into the insulator.
4. Push the plunger downward to extract the contact.

Warning: - If the plunger is operated at the “first resistance,” before the forks are fully inserted, the forks will bend rendering the tool unusable.