





PSM700 Frequency Chart Supplement



H3		
CHANNEL	GROUP 1 (MHz)	GROUP 2 (MHz)
0	524.200	553.800
1	525.150	552.850
2	526.825	551.175
3	530.375	547.625
4	531.000	547.000
5	533.300	544.700
6	538.150	539.850
7	545.625	532.375
8	546.925	531.075
9	550.150	527.850
A	551.625	535.025
B	553.575	541.650
C	537.325	536.350
D	527.975	543.250
E	540.675	551.125
F	542.725	553.375



H3		
CHANNEL	GROUP 1 (MHz)	GROUP 2 (MHz)
0	524.200	553.800
1	525.150	552.850
2	526.825	551.175
3	530.375	547.625
4	531.000	547.000
5	533.300	544.700
6	538.150	539.850
7	545.625	532.375
8	546.925	531.075
9	550.150	527.850
A	551.625	535.025
B	553.575	541.650
C	537.325	536.350
D	527.975	543.250
E	540.675	551.125
F	542.725	553.375