



TECHNICAL DATA SHEET

TRIAX AUTOMATIC CABLE TESTER

25-005 CANFORD TRIAX CABLE TESTER Fischer

25-006 CANFORD TRIAX CABLE TESTER LEMO

DESCRIPTION

The Cable Tester can be used for testing long or short cables, either fixed or installed. The separate REMOTE barrel allows easy testing of cables where both ends of the cable are not available together. Poor solder joints or high resistance is shown by a reduction in the intensity of the display illumination. A table of the main fault conditions is printed on the Cable Tester.

CONNECTORS

The SEND section consists of Female Socket Triax connector

The separate REMOTE barrel consists of Male Plug connector

CABLE TESTING

Switch on the cable tester ensuring that the red LED illuminates. If this is not the case then fit or replace battery. (See POWER SUPPLY section.) Connect the cable to be tested to the appropriate connectors, one end to the SEND section and the other to the REMOTE barrel. The condition of the cable should then be displayed. If no LEDs illuminate then press the TEST button. Follow the explanation on the top of the unit to indicate the condition of the cable.

POWER SUPPLY

The cable tester is powered by one 9 volt battery.

Alkaline or rechargeable types are recommended.

Batteries:	Alkaline	59-026 Varta 4022
		59-045 GP 1604A
		59-121 Procell MN1604 (10 pack)
Rechargeable		59-065 GP 17R8H

Batteries are available individually unless stated otherwise.

Battery replacement:

LIFT TO WITHDRAW as directed on the battery compartment, replace the battery, observing correct polarity and slide the drawer home again.