



PAGlink™ MICROCHARGER

V-Mount & Gold Mount Models



INSTRUCTIONS

The following items (and a power plug) are included:



Micro Charger

AC Power Supply Unit



USB DC Lead

In-Vehicle DC Lead



PAG Ltd. UK 565 Kingston Road, London SW20 8SA
T +44 (0)20 8543 3131 E sales@paguk.com
www.paguk.com

PAG America 18 Center Street, Ramsey, NJ 07446 USA
T +1 631 300 8215 E sales@pagamerica.com

1. Safety Information

- 1.1 PLEASE READ THIS IMPORTANT SAFETY INFORMATION FULLY AND NOTE ALL WARNINGS BEFORE USING THE CHARGER.** Follow all the operating instructions and retain this leaflet for future reference.
- 1.2** The PAGlink Micro Charger is not intended for any use other than the charging of batteries as detailed in 'Specification'.
- 1.3 IMPORTANT:** The Power Supply Unit is designed for use on 100-240V, 50-60Hz AC supplies. AC supply connection to the charger should be made using only the Power Supply Unit and plug supplied with this charger. The Power Supply Unit supplied with the previous Micro Charger Model 9710 is not suitable for use with Models 9713 or 9713V.

The charger is designed for 5-20V DC input only. Connection to DC supplies should be made using only the power leads supplied with the charger. The USB charger connection must be 2A or more.

- 1.4** Protect any power cables from being walked on or pinched. Unplug the apparatus during lightning storms or when unused for long periods of time.
- 1.5 WARNING: INDOOR USE ONLY.** To reduce the risk of fire or electric shock, do not expose the charger to rain or moisture.
- 1.6** Although the charger is reverse polarity protected, extreme care should always be taken not to short circuit the battery itself. Rechargeable batteries can deliver power at a very high rate, and short circuiting even a partially charged battery could result in a fire or personal injury.
- 1.7** Do not disassemble the charger. There are no user-serviceable parts inside. Incorrect reassembly may result in a safety hazard.
- 1.8** If any part of the charger has been damaged, if it has been exposed to moisture, rain or liquid, or if it does not operate normally, you should seek advice from your nearest **PAG Authorised Service Centre:**

PAG America:
T: +1 631 300 8215, E: sales@pagamerica.com

PAG UK:
T: +44 (0)20 8543 3131, E: support@paguk.com

If you are located outside the US and the UK please visit www.paguk.com/agents to discover your nearest point of contact.

2. Specification

- 2.1 Micro Charger Models covered by these instructions:**
Model 9713V (V-Mount).
Model 9713 (Gold Mount).
- 2.2 Range of Batteries Charged:**

Model 9713V is designed for charging the following PAGlink V-Mount Li-Ion batteries, individually or linked:

- Model 9303 PAGlink PL96e
- Model 9304 PAGlink PL96T
- Model 9308 PAGlink PL150e
- Model 9309 PAGlink PL150T

It is also suitable for charging individually the following non-linking V-Mount Li-Ion batteries:

- Model 9307V PAG L90 Slim
- Model 9310V PAG L95e/L96e
- Model 9305V PAG L96T
- Sony V-Mount Li-Ion

Model 9713 is designed for charging the following PAGlink Gold Mount Li-Ion batteries, individually or linked:

- Model 9306 PAGlink PL94T
- Model 9313 PAGlink PL150T

It is also suitable for charging individually the following non-linking Gold Mount Li-Ion batteries:

- Model 9310A PAG L95e/L96e
- Model 9305A PAG L96T

2.3 Charging Multiple PAGlink Batteries:

The Micro Charger is designed for charging simultaneously up to 4 linked PAGlink batteries of any rated capacity and from any state of charge.

2.4 Main Charge Program:

Li-Ion voltage-charge program.

2.5 Recovery Charge:

This special program will automatically recover a PAG Li-Ion battery where the output has been shut down.

2.6 Self Test Program:

The internal microprocessor constantly monitors the battery under charge or process as well as the operation of the charger's own functions which will be shut down to a safe condition should any of the tests fail.

2.7 Input:

Charger: DC 5-20V. Connector: 2.1mm DC (PP90), any polarity. Power Supply Unit: AC 100-240V ~ autoselected. Frequency 50-60 Hz. Maximum power consumption 35W.

2.8 Output Protection:

Protected against short circuit and open circuit.

2.9 Power Input Failure Protection:

Should power failure occur during a charging program, or whilst the charger is connected, it will shut down to a safe condition.

2.10 Charger Display:

LED indication is provided of battery absent, battery charging, charge completion and a faulty battery. The charger is fully automatic in operation and there are no user controls.

2.11 State of Charge Indication:

Each battery indicates its individual state of charge, during charging, via its Run-Time & Capacity display.

2.12 Operating Temperature Range:

0°C to +40°C (+32°F to +104°F).

2.13 Dimensions (L x W x H):

Model 9713V V-Mount Micro Charger:
73 x 62 x 31mm (2.9" x 2.5" x 1.25").

Model 9713 Gold Mount Micro Charger:

73 x 62 x 33mm (2.9" x 2.5" x 1.25").

2.14 Weight

Both Models: 75g (2.6oz).

2.15 Typical Battery Charging Times:

1	94/96Wh battery	4	hours
2	94/96Wh batteries	8	hours
3	94/96Wh batteries	12	hours
4	94/96Wh batteries	16	hours

These charge times are for fully-discharged batteries to fully-charged.

150Wh batteries will take 50% longer.

Charge times will be less when batteries are only partially discharged.

Charge time will be 10 hours approximately for a 94/96Wh battery, when the Micro Charger is powered from a USB charger (2A).

3. Operating Instructions

3.1 Powering the charger from an AC input:

The charger is supplied with a Power Supply Unit that automatically accepts AC input in the range 100-240V (See Specification). Connection of the charger to an AC supply should be made using only the Power Supply Unit included, fitted with the power plug supplied, or one of the alternative power plugs available from PAG or its agents:

Model 9713J USA/Japan Model 9713U UK
 Model 9713E Europe Model 9713A Australia

IMPORTANT: The Micro Charger must be powered-up before connection to the battery.



Fig. 1. Fit the appropriate plug to the Power Supply Unit. Connect the PSU to a suitable AC supply (100-240V See Specification).



Fig. 2. Connect the Power Supply Unit to the Micro Charger.



Fig. 3. Slide the Micro Charger over the contacts on the rear of the battery.

3.2 Using the DC Power Leads

The charger can be powered from DC inputs in the range 5 to 20V, such as a 12V vehicle battery (via a dashboard lighter socket) or a USB charger (2A). Connection to DC input should only be made using the DC power leads supplied.

IMPORTANT: The Micro Charger must be powered-up before connection to the battery. Connect the DC power cable supplied to the Micro Charger (See Fig. 2). Plug the male connector into the lighter socket on the vehicle dashboard, or plug the USB connector into the socket on the USB charger (2A). Slide the charging shoe over the contacts on the rear of the battery (See Fig. 3).

The PAGlink Micro Charger may be disconnected from the supply at any time in complete safety, and without damage to the charger or any of the batteries connected.

3.3 On power-up, the charger will automatically run a self-test program and then the Recovery Charge program. Any batteries that are connected to the charger but which do not require the Recovery Charge program will begin charging.

3.4 Key to the PAGlink Micro Charger LED indication:

RED	Constant	=	ABSENT
ORANGE	Flashing	=	CHARGING
GREEN	Constant	=	FULLY CHARGED
RED	Flashing	=	FAULTY

With no batteries connected, the charger's LED status indicator will be lit **RED** (constant).

Charging will start automatically. The status indicator will flash **ORANGE**. The state-of-charge of each battery will be indicated on its individual display.

The charger's status indicator will light **GREEN** when all the batteries connected have received as much charge as they can safely accept.

Batteries may be removed, and others connected at any time, without affecting the operation of the charger.

If a new battery is connected, the charging sequence will be initiated automatically. The most discharged battery will be addressed first. The order in which batteries are connected is therefore immaterial; the charger will ensure that all the batteries are fully-charged in due course.

3.5 If the charger detects a severely faulty battery while the charging program is running, the battery status indicator will flash **RED**. This could be caused by one of several conditions, such as a very old or damaged battery, a short circuit battery, an excessively high or low voltage battery, or an excessively high or low supply voltage. The charger is reset by disconnecting it from the supply.

3.6 The charger will not recognise the connection of a battery that has a voltage substantially outside of its range.

3.7 If the internal protection circuit of a PAG Li-Ion battery should turn off for any reason, the battery display will not operate, and there will be no voltage at the battery terminals. The PAGlink Micro Charger incorporates a Recovery Charge program which will automatically turn the protection circuit back on again.

3.8 If power fails during operation, the charger will shut down safely; no damage will occur to either the charger or the batteries. When the power is restored the charger will default to the main charge program.

4. Servicing & Repairs

4.1 The PAGlink Micro Charger contains advanced electronics that do not require periodic maintenance; consequently there are no user-serviceable parts inside.

4.2 **WARNING:** To avoid the risk of electric shock, do not disassemble the charger's Power Supply Unit. Refer all servicing or repairs to a PAG authorised service centre.

Qualified electronics engineers who wish to gain access to internal assemblies should note that parts of the power circuit retain a high voltage even after the AC mains supply has been disconnected. Wait for a period of five minutes following disconnection before commencing disassembly and be aware of charged capacitors.

4.3 Seek advice if the charger is not operating normally or if any of the following situations occur:

The charger is correctly connected to the power and the display is not functioning.

The charger ceases to operate after entering fail-safe shutdown mode (allow it to cool before reconnecting to the supply).

The charger has been damaged or suffered a severe blow.

The charger has been exposed to moisture, rain or any other liquid.

Contact a PAG Authorised Service Centre:

PAG America:

T: +1 631 300 8215, E: sales@pagamerica.com

PAG UK:

T: +44 (0)20 8543 3131, E: support@paguk.com

If you are located outside the US and the UK please visit www.paguk.com/agents to discover your nearest point of contact.

5. Guarantee

5.1 Notwithstanding any provision of any agreement the following guarantee is exclusive: PAG Limited guarantees each Micro Charger it manufactures to be free of defects in material and workmanship under use and service for **TWO YEARS** from the date of purchase. This guarantee extends only to the original purchaser. This guarantee shall not apply to fuses or any product or parts which have been subject to misuse, neglect, accident or abnormal conditions of operation.

5.2 In the event of failure of a product covered by this guarantee, PAG Limited will repair and calibrate equipment returned to an Authorised Service Centre within the period of the guarantee, provided the guarantor's examination discloses to its satisfaction the product was defective. The guarantor may, at its option, replace the product in lieu of repair. With regard to any equipment returned within this period, said repairs or replacements will be made without charge. If the failure has been caused by misuse, neglect, accident or abnormal conditions of operation, repairs will be billed at a nominal cost. In such a case, an estimate will be submitted before work is started, if requested. For more information visit www.paguk.com

INTERNATIONAL PATENTS APPLY

See: paguk.com/patents

Disclaimer:

The information contained in this document is correct at the time of publication. PAG Ltd. reserves the right to change specifications or product details without notification. Changes to product details will be incorporated in the next version of the document. PAG updates its documents on a regular basis.

Trademarks:

All PAG registered trademarks are the property of PAG Ltd. All third party trademarks are acknowledged as such.

Copyright © 2018 PAG Ltd. All rights reserved